

(e) *Confirmatory sampling for the validation study.* Select surface sample locations using representative sampling or a census. Sample a minimum area of 100 cm² on each individual surface in the validation study. Measure surface concentrations using the standard wipe test, as defined in § 761.123, from which a standard wipe sample is generated for chemical analysis. Guidance for wipe sampling appears in the document entitled "Wipe Sampling and Double Wash/Rinse Cleanup as Recommended by the Environmental Protection Agency PCB Spill Cleanup Policy," available from the TSCA Assistance Information Service, Environmental Protection Agency, 401 M St., SW., Washington, DC 20460.

(f) *Concentration of PCBs.* The method validated may be used only to decontaminate surfaces containing PCBs at concentrations on which the validation study was performed and lower concentrations.

§ 761.389 Testing parameter requirements.

There are no restrictions on the variable testing parameters described in this section which may be used in the validation study. The conditions demonstrated in the validation study for these variables shall become the required conditions for decontamination using the solvent being validated and shall replace the comparable conditions in § 761.79(b)(3) through (b)(6). There are limited potential options for varying a single requirement in this section. If you change one of these variable requirements, change it only in the way listed in this section and do not change any other validated conditions. If you desire to change more than one of the requirements in this section, you must conduct a new study to validate the decontamination under the desired conditions.

(a) The study apparatus is not standardized. Critical components of the study are the PCB material (for example MODEF or some other spiking solution), the volume of the soaking solvent, and the area of the contaminated surface. The EPA study used beakers and shallow dishes as the experimental vessels to contain the surface and solvent during the soaking process. In order to minimize surface-to-volume

ratios, it is convenient to utilize flat contaminated surfaces and shallow solvent containers. During the validation study, use the same ratio of contaminated surface area to soak solvent volume as would be used during actual decontamination. It is also permissible to use a smaller surface area to soaking solvent volume than used in the validation study, so long as all other required parameters are used as validated in the confirmation required in § 761.386 (a) through (f), and paragraphs (a) through (c) of this section. Do not use a larger surface-area-to-solvent-volumes ratio or different kind of solvent based on the results of the validation study.

(b) Except for the minimum soak time of 1 hour (as required in § 761.386(c)), the length of soak time is not otherwise restricted in the validation study. The soak time used in the validation study, however, is a use requirement for subsequent decontamination using the solvent being validated. It is permissible to use longer soak times for decontamination than the soak time used in the validation study, if all other parameters required in § 761.386, and paragraphs (a) and (c) of this section are used.

(c) There is no restriction on the kind of material containing PCBs to use to create the surface contamination for the validation study. There is also no restriction on the level of starting PCB surface concentration. It is permissible to use lower concentrations of PCB than the concentration used in the validation study, if all other parameters required in § 761.386 (a) through (f), and paragraphs (a) through (c) of this section are used.

§ 761.392 Preparing validation study samples.

(a)(1) To validate a procedure to decontaminate a surface contaminated with a spill from liquid of a known concentration, contaminate (spike) the surface to be used in the validation study as follows:

(i) Use a spiking solution made of PCBs mixed with a solvent to contaminate clean surfaces. Clean surfaces are surfaces having PCB surface concentrations <1 µg/100 cm² before intentionally contaminating the surface.

§ 761.395

(ii) Prior to contaminating a surface for the validation study, mark the surface sampling area to assure that it is completely covered with the spiking solution.

(iii) Deliver the spiking solution onto the surface, covering all of the sampling area. Contain any liquids which spill or flow off the surface. Allow the spiking solution to drip drain off into a container and then evaporate the spiking solution off the contaminated surface prior to beginning the validation study. Contaminate a minimum of eight surfaces for a complete validation study.

(iv) As a quality control step, test at least one contaminated surface to determine the PCB concentration to verify that there are measurable surface levels of PCBs resulting from the contamination before soaking the surface in the decontamination solvent. The surface levels of PCBs on the contaminated surfaces must be $\geq 20 \mu\text{g}/100 \text{ cm}^2$.

(2) To validate a procedure to decontaminate a specified surface concentrations of PCBs as measured by a standard wipe sample, contaminate a minimum of 10 surfaces. Contaminate all the surfaces identically following the procedures in paragraph (a)(1) of this section and measure the PCB surface concentrations of at least three of the surfaces using a standard wipe test to establish a surface concentration to be included in the standard operating procedure. The surface levels of PCBs on the contaminated surfaces must be $\geq 20 \mu\text{g}/100 \text{ cm}^2$.

(b) [Reserved]

§ 761.395 A validation study.

(a) Decontaminate the following prepared sample surfaces using the selected testing parameters and experimental conditions. Take a standard wipe sample of the decontaminated surface.

(1) At least one uncontaminated surface. The surface levels of PCBs on the uncontaminated surface must be $< 1 \mu\text{g}/100 \text{ cm}^2$.

(2) At least seven contaminated surfaces.

(b)(1) Use SW-846, Test Methods for Evaluating Solid Waste methods for sample extraction and chemical anal-

40 CFR Ch. I (7-1-00 Edition)

ysis as follows: Use Method 3500B/3540C or Method 3500B/3550B for the extraction and cleanup of the extract and Method 8082 for the chemical analysis, or methods validated under subpart Q of this part.

(2) Report all validation study surface sample concentrations on the basis of micrograms of PCBs per 100 cm^2 of surface sampled.

(c) Following completion of the validation study, measurements from the contaminated surfaces must have an arithmetic mean of $\leq 10 \mu\text{g}/100 \text{ cm}^2$. If the arithmetic mean is $> 10 \mu\text{g}/100 \text{ cm}^2$, then the validation study failed and the solvent may not be used for decontamination under § 761.79(d)(4) according to the parameters tested.

§ 761.398 Reporting and record-keeping.

(a) Submit validation study results to the Director, National Program Chemicals Division (NPCD), (7404), Office of Pollution Prevention and Toxics, 401 M St., SW., Washington, DC, prior to the first use of a new solvent for alternate decontamination under § 761.79(d)(4). The use of a new solvent is not TSCA Confidential Business Information (CBI). From time to time, the Director of NPCD will confirm the use of validated new decontamination solvents and publish the new solvents and validated decontamination procedures in the FEDERAL REGISTER.

(b) Any person may begin to use solvent validated in accordance with this subpart at the time results are submitted to EPA.

(c) Record all testing parameters and experimental conditions from the successful validation study into a standard operating procedure (SOP) for reference whenever the decontamination procedure is used. Include in the SOP the identity of the soaking solvent, the length of time of the soak, and the ratio of the soak solvent to contaminated surface area during the soaking process. Also include in the SOP the maximum concentration of PCBs in the spilled material and the identity of the spilled material, and/or the measured maximum surface concentration of the